



DESCRIPTION

Ensure mains are switched off

- A. Loosen grub screw.
- B. Unscrew cord grip.
- C. Make connection to main power, fix bracket to ceiling using screws provided.
- D. Fix the cord grip and grub screw.
- E. Unscrew the fitting.
- F. Place your desired shade between two rubber seals, and sandwich between fitting.

